


1. Place the Controller Firmware Disc in the source drive of the ReflexMax 7 Make sure you source is the first drive and not the hard drive.

```
Src: DVD-DUAL  
01 IDE1 Master
```

2. Hold down the **ESC** Button until the ReflexMax 7 beeps and the LCD says 12-01 ADV SETUP Under Run Protect.

```
12-01 ADV SETUP  
UnderRun Protect
```

3. When you are in ADV SETUP use the down arrow  to 12-07 Update Firmware and press **ENT**.

```
12-07 ADV SETUP  
Update Firmware
```

4. It will load the firmware and the controller will boot back up and the firmware will be updated.