



1. Press and hold the ESC button

A solid red square with the letters "ESC" in a bold, black, sans-serif font centered within it.

2. This will bring you into 'Advanced Setup'

A blue rectangular area representing a screen display. The text "12-01.ADV Setup" is on the top line and "UnderRun Protect" is on the bottom line, both in a white, monospaced font.

3. Scroll to 'Switch USB Mode'

A blue rectangular area representing a screen display. The text "12-13.Adv Setup" is on the top line and "Switch USB Mode" is on the bottom line, both in a white, monospaced font.

4. Press ENT

A solid green square with the letters "ENT" in a bold, black, sans-serif font centered within it.

5. The display will read USB L.A. Mode

A blue rectangular area representing a screen display. The text "USB L.A. Mode" is centered on the screen in a white, monospaced font.


Your USB is now enabled!

To disable USB:

1. Press one of the arrow keys



2. The display will read 'Back To SA-Mode? Yes



3. Press ENT



Your USB is now disabled.